

Bisley+ Desk Assembly Instructions

What You'll Need


(A) 1 desktop, (B) 1 Bisley Steel Home File Cabinet, and (C) 2 hairpin legs with (D) 2 floor protectors. Hardware package includes: (E) 1 hex wrench, (F) 8 button head bolts, and (G) 2 rubber grips.



Note: assemble on a level soft surface with at least two people to ensure safe assembly and to prevent damage.

Assembly

1. Place the (A) desktop on a level soft surface with the 16 bolt holes facing up.
2. Place (C) hairpin legs over existing bolt holes and screw in to place using the (E) hex wrench with (F) button head bolts, use 4 button head bolts per leg (*see diagram*).
3. Screw in (G) rubber grips by hand on the other side, in the two holes nearest the center.




4. Once assembled and tightened fully, flip the desktop over (*with the help of a second person*).
5. Position the assembled desktop with hairpin legs over the (B) cabinet so that the legs are to the left or right of the cabinet (*either placement will work*). Lower the side with rubber grips onto the Bisley Cabinet. You can easily reposition the desk by rotating the desktop and legs to the other side (*see images below*).

Bisley left side alignment




Bisley right side alignment



Bisley+ Desk Assembly Instructions

Assembly Continued

6. Align the edge of the (A) desktop with the edge of the (B) Bisley Cabinet. Center the cabinet under the desktop and ensure both (G) rubber grips are resting on top of the cabinet (see diagram).
7. Optional step: place (D) floor protectors under the (C) hairpin legs if using desk on a wood or tile floor.



Enjoy your new Bisley+ Desk!

